



MINMAX

θερμόμετρο
thermometer

-40°+50°C

ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ

Το θερμόμετρο αυτό καταγράφει τις κατώτερες & ανώτερες θερμοκρασίες νυκτός και ημέρας.

Πιέστε το κουμπί έτσι ώστε οι 2 μπλε δείκτες να βρίσκονται σε επαφή με τον υδράργυρο. Θα κινηθούν ανάλογα με τις διαφορές της θερμοκρασίας και θα σταθεροποιηθούν στις κατώτερες & ανώτερες θερμοκρασίες που θα καταγραφούν. Αυτές διαβάζονται στο κάτω μέρος των 2 μπλε δεικτών του θερμομέτρου.

Σε περίπτωση που οι στήλες του Υδραργύρου έχουν διαχωριστεί λόγω μεταφοράς, κρατήστε το θερμόμετρο σε οριζόντια θέση και αναταράξτε το λίγο αλλά δυνατά (όπως ένα ιατρικό θερμόμετρο) για να ανασυνταχθεί ο Υδράργυρος.



DIRECTIONS FOR USE

This instrument determines the day's maximum and the night's minimum temperatures.

Press the button so that the 2 blue indicators are in contact with the mercury. They will move according to the change in temperature and will freeze on the maximum and minimum temperatures recorded. These are to be read at the bottom of the blue indicators on either side of the thermometer.

Should the Mercury column have become separated during transport, hold the thermometer horizontally and shake slowly but forcefully (like a medical thermometer) in order to regroup the Mercury.

ΚΑΔ: 61385